

Iron-On Inkjet Glitter Fabric Transfer Instructions

Glitter transfer sheets are opaque white sheets for use with inkjet printer
Please read the instructions carefully prior to use for optimal results

What you need...

- Glitter metallic transfer sheets
- Parchment paper (included in package)
- Household hand iron
- Pillow cover or thick cotton cloth.
- Inkjet printer
- Smooth, heat resistant, hard surface.
Example: wood cutting board, flat wooden table surface. Do not use ironing board, glass, or any heat sensitive surfaces.

Create your image

- Design your image on the computer using graphics, text or photos.
- Test by printing your image on a sheet of plain paper if desired. Do not use mirror image / reverse / T-shirt setting on your printer. There is no need for flipping the image.
- Once you are satisfied with how your image looks, insert single sheet of Reflective Metallic transfer sheet into your inkjet printer. It is easy to tell which side to print on, as the printing side is white, opaque and a little rough.
- Suggested settings:
- Paper Type: Plain paper
- Print Quality: Best / High resolution
- you can use your own settings – what you print is what you get when transferred
- Using a scissors or craft knife, trim out image to desired shape.
- Gently peel the finished printed image from the backing paper.

Transfer your image

- Place the pillowcase on the ironing surface and smooth it flat so that there are no wrinkles.
- Do not use ironing board, bare wood, glass, or metal surface for ironing.
- Lay the fabric, T-shirt on the work surface. Pre-iron fabric to remove any moisture and wrinkles.
- Confirm temperature setting of hand iron is 350° F or cotton setting.
- Place the iron on transfer image side facing up on the fabric, T-shirt.
- Lay the parchment / ironing sheet over the surface of the transfer.
- Use firm downward pressure. For best results hold iron with both hands lean in with body weight. Iron one area/spot at a time for 1 – 1.5 minutes and complete ironing the entire image in overlapping fashion. Make sure to completely iron the entire area especially the edges and corners. If using an industrial heat press, hold press down for 30 seconds.
- Let the fabric cool down for ~2-3minutes (cool to touch) before removing the release/parchment sheet.
- Peel away parchment sheet / release liner in a smooth even motion.

Washing

- Always turn your garment inside out (transfer side in). This will minimize the amount of abrasion it will encounter help extend the life of the transfer.

- Wash the garment in cold water using a mild detergent. Do not use bleach.