



# JetWear™ SilverLine

## Cold-Peel Inkjet Transfer Paper


version 1.4.2

### You Will Need:

- White or light color Cotton, Cotton/Polyester Blend, or stretchable fabrics like Lycra™
- Heat Press or Iron and pillowcase
- Hard smooth surface (ex: Formica, NOT AN IRONING BOARD)

### 1. Printing The Transfer

- Insert a single sheet of transfer paper into the printer with the printable surface (non-glossy/unlined side) loaded correctly for your printer. (See your printer manual if necessary.)
- Mirror or flip image prior and Print.
- Trim away any unprinted paper around the image.



### 2. Transferring Using Commercial Heat Press

- Preheat press to 350°F press garment for 3-5 secs to release moisture and wrinkles.
- Place transfer on garment (print side down)
- Press with medium pressure for 30 seconds to 3 minutes
- Cold Peel - wait until transfer cools (at least 2 minutes) and remove backing using a smooth, even motion.

### 3. Washing Instructions

- Wash garment separately (first time only). Turn inside out.
- Machine wash cold with color-safe detergent. No bleach.
- Remove promptly from washer to prevent bleeding. If bleeding occurs, rewash immediately.
- Tumble dry with low heat. Add towels to facilitate drying.

### 4. Storing Unused Transfers

- After opening JetWear™ transfer paper, store unused sheets in a resealable poly bag on a flat, cool and dry area.

### 5. Hand Ironing Times

- For a full-page transfer, iron for 3 minutes in illustrated pattern
- For a half-page transfer, move iron in continuous circles for 90 seconds.
- For a quarter-page transfer, move iron in continuous circles for 45 seconds, or for 30 seconds if smaller than a quarter-page.

### 6. Transferring a Hard-Iron


#### 1. Using a Hand-Iron

- Preheat iron for 5 minutes on hottest setting. Do not use steam setting - empty any water!
- For proper pressure, use an ironing surface that is waist-level or lower. Do not use ironing board, glass, concrete, granite, or any soft or heat-sensitive surface!
- Fold the pillowcase in half and place it on the ironing surface with the open end hanging over the edge. Iron pillowcase to remove any wrinkles.
- Place garment over the center of the pillowcase. Iron the garment to remove any wrinkles.
- Center the transfer paper--image side down--on garment.




#### 2. Hand-Ironing Your Transfer

- Step A: Holding the iron as pictured, firmly slide across transfer paper from right to left, making 4 equal passes of 20 seconds each. Be sure to pass over all edges.



- Step B: Holding the iron as pictured, firmly slide the iron from bottom to top, making 5 passes of 20 seconds each. Be sure to pass over all edges.



#### IMPORTANT NOTES:

##### Printer & Copier Inks

T-ShirtSupplies.com offers papers for inkjet, laser, and thermal wax printers and copiers. In all cases, our papers are optimized to perform with OEM inks and toners. T-ShirtSupplies.com does not warrant use of aftermarket inks and toners, and cannot guarantee results. We recommend that you test any non-OEM inks or toners prior to use.

##### Product Quality Assurance

T-ShirtSupplies.com conducts exhaustive testing on all its products, using many types of substrates, printers, copiers, heat presses, irons, and laundry detergents. However, it is impossible to duplicate all printing and transfer processes, so we recommend testing your chosen paper to determine its suitability to your needs and equipment. Please visit our knowledge base at [www.tshirtsupplies.com](http://www.tshirtsupplies.com) for more information.